Dansensor® CheckMate 4 ACCURATE, FAST AND RELIABLE HEADSPACE GAS TESTING



A flexible and reliable analyzer with maximum uptime

The Dansensor CheckMate 4 is our premier headspace gas analyzer – a compact tabletop instrument that combines extreme accuracy and reliability with an intuitive user experience. The multilingual touchscreen helps minimize the training time needed for new operators. At the same time, individual user logins provide limited access to functions, helping to secure data and traceability.

Save product test settings to ensure complete and comparable data records. Quickly switch between product test settings on-screen or by scanning the product's barcode with the optional barcode scanner.

Automated data storage and real time data transfer ensure accuracy and speed by eliminating the time and risk associated with manual data entry. Optional PC software makes it easy to monitor data across multiple packaging lines and prepare for audits.

The Dansensor CheckMate 4 includes an improved sample system and pump to avoid blockages and ensure smooth operation. The instrument's sensor module can be upgraded to a newly calibrated module on-site in minutes.*

Benefits

- Reliable, accurate measurements protect your product and brand
- Increase efficiency with short test times and automated data logging
- Easy to use with intuitive touchscreen
- Maximize uptime with improved pump and sample system
- Reduce errors with defined test programs, automated data handling and user logins

Features

- O₂ or combined O₂/CO₂ headspace measurements – flexible configuration
- Very small sample gas volume
- Save test settings for quick changes and comparable results
- Data storage and real time data transfer
- Fast and secure LAN connection
- Touchscreen with multilingual graphic interface
- Individual user logins provide security and reduce risk of errors
- Alarm alerts when pre-set gas limits
 exceeded
- USB port for connecting optional barcode scanner, keyboard or printer



HOW DOES IT WORK?

- 1. Identify the correct test program by scanning the product's barcode or manually selecting the correct test definition.
- 2. Place a septum on the package and insert the needle through the septum, into the package. Start the test with the touch of a button
- **3.** During the test, a small sample of the headspace gas is analyzed. The result is automatically stored on the unit.
- **4.** Test results can be printed on an optional printer or exported via LAN (real time transfer) or a USB drive. Import the data to Dansensor CheckMate 4 PC software or to your own database for analysis.



Available configurations	O ₂ (zirconia)	O ₂ (electrochemical)	CO ₂ (infrared dual beam)
Key features	Fastest and most accurate oxygen sensor	Not sensitive to alcohol, carbon monoxide or carbon dioxide	Full-scale, temperature compensated carbon dioxide sensor
Sample volume (minimum)	2 ml	5 ml	5 ml
Sample time (minimum)	3 sec	7 sec	8 sec
Measuring range	0-100%	0-100%	0-100%
Resolution	Under 10% O ₂ : 0.001% Over 10% O ₂ : 0.01%	0.1%	0.1%
Accuracy	Under 1% O ₂ : ±0.01% Over 1% O ₂ : ±1% of readout	±(0.25% absolute + 2% of readout)	±(0.5% absolute + 1.5% of readout)
Heating time	10 min	n/a	10 min
Applications	Most food and healthcare applications	Packages containing ethenol (i.e. fresh bread products)	Most food and healthcare applications with carbon dioxide
Calibration and service*	12 months	6 months	12 months
Number of product test settings	999		
Data collection capacity	Log results of up to 1,000,000 tests		
Data export	Stored data to CSV file (USB) or real time data transfer CSV-string per test (RJ-45). Compatible with CheckMate 4 PC software, Microsoft SQL datbases and other select third party software.		
Dimensions (WxDxH) and weight	305 x 240 x 187mm (12" x 9.4" x 7.4"); 4.2 kg (9.3 lbs)		
Ambient temperature	Operational: 0°C to +35°C Storage: -20°C to +60°C		
Relative humidity	Operational: 10 to 90 %RH (non-condensing) Storage: less than 95 %RH (non-condensing)		
Power supply and consumption	100-240 VAC, 47-63 Hz Max 70W		
Connections	LAN: RJ-45 Ethernet 10/100 Mbit/s, DHCP client or fixed IP USB: 1 x Host, USB 2.0 Type A; 1 x Device, USB 2.0 Type B (max current 500 mA)		
Consumables and accessories	Septa, filters, needles, sample hose (kit), CheckMate 4 PC software, SmartPen retractable needle, can piercer for testing cans and wine bottles, barcode scanner		
Warranty	12 months		
Compliance	CE, China RoHS II		

Technical Specifications

Specifications subject to change without notice. * Sensor lifetime depends on usage patterns.



